


ENGLISH

Instruction for use of XENIC Men's Shaver

Note:
Open these instructions completely and read them carefully before using your new shaver.

Content

1) Components
2) Safety instructions
3) Operation
4) Application
5) Cleaning and care
6) Changing foil and cutter blocks
7) Replacement parts
8) Warranty
9) Environmental protection / disposal

1) Components

(see left side of folder)
Compare the drawings with the components of your shaver to make yourself familiar with it.

① Protective cap
② Shaver head
③ Shaving foil
㉛ Integrated long hair trimmer
④ Cutter blocks
⑤ ON / OFF switch
㊶ Travel lock
⑥ Charge indication battery symbol only
⑦ Long hair trimmer
⑧ Shaver head release buttons
⑨ Locking button "Lift & Wash"
⑩ Socket for charging cable
⑪ Safety power plug
⑫ Cleaning brush

2) Intended Use and Safety Information

- This shaver is for private use only, and is not authorized for commercial purposes. Use indoors only.
- It has been designed to shave beard hairs, and is suitable only for natural human hair, not for animal hair.
- Read the instructions for use before using the shaver! Risk of electric shock and fire!
- Plug in the device and operate it only in accordance with the information given on the rating plate.
- Do not use if the supply line or the device shows any sign of damage. Keep the device away from children.
- **Do not use the device near filled bathtubs, sinks or other containers filled with liquids.**
- Do not touch the plug-in mains adapter with wet hands.
- Pull the plug-in mains adapter out of the electric socket immediately after use.

- Do not use while bathing.
- Do not place the device anywhere that it could fall or be pulled into a filled bathtub or a filled sink.
- Never immerse the device or the plug-in mains adapter in water or another liquid.
- If the device falls into water, unplug the mains plug immediately. Do not reach into the water.
- Installation in the housing wiring of a residual current circuit breaker with a nominal release current of not more than 30 mA offers additional protection. Contact your electrician for this.
- Never use a defective device or defective plug-in mains adapter.
- Have repairs made only by an expert retailer or by our Service Centre (see page 20).
- Do not cover the plug-in mains adapter, because doing so could cause excessive heating due to heat build-up.
- Plug the plug-in mains adapter only into an easily accessible socket with earth contact.
- Do not pinch the plug-in mains adapter connection cable incupboard doors or pull it across hot surfaces.
- The plug-in mains adapter connection cable cannot be replaced. Should the plug-in mains adapter or its connection cable be damaged, it must be disposed of properly.
- Replace a defective plug-in mains adapter only with a plug-in mains adapter of the same type.
- Do not expose the shaver to temperatures less than –10° C or more than +40° C. Do not place the shaver on heaters or radiators, because this increases the risk that the rechargeable battery will leak.
- Avoid skin, eye and mucous membrane contact with any fluid leaking out of the rechargeable battery. If there is contact with rechargeable battery liquid, rinse affected areas off immediately with ample clear water and see a doctor promptly.
- Use the shaver only on natural hair.
- Use of the men's shaver for commercial purposes is not authorized.
- Ensure that the shaver is switched off after use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.

3) Operation

The shaver can be operated by connecting it to the mains or with the rechargeable batteries.

- To reach optimum rechargeable battery capacity, the batteries should be initially charged for 8 hours before the shaver is used for the first time.
- When the shaver is charging the green battery symbol ⑥ is lightning.
  When the Shaver is fully charged this light flashes.
- The shaver is full charged within 1 hour.
- Continuous charging is to be avoided. Use the shaver normally until the batteries are completely discharged before fully recharging them again.
- To maintain optimum charge capacity this charging / discharging procedure should be repeated several times a year.
- A full charge will give you up to 45 min. cordless shaving time.

4) Application

Foil shaving

For best shaving results use the shaver on dry, clean skin. However you can also use the shaver with shaving foam.

- Hold the shaver at a right angle to your skin against the direction of growth of the stubble (Fig. 1). Apply only light pressure.



- Stretch the skin with your free hand so that the hairs stand upright (Fig. 2).



If you are using a foil shaver for the first time, it generally takes about two to three weeks for the skin to get used to foil shaving.

- After shaving, put the protective cap ① back on to the shaver head ②. Avoid pressure on the foil as this may cause damage of the foil.
- The integrated long hair trimmer ㉛ is used for shortening longer beard stubble in order to have a more efficient foil shave.

Long hair trimmer

The separate long hair trimmer ⑦ on the back side of the product can easily be extended by sliding it upwards until it clicks in position (Fig. 3).



It is particularly used for beard trimming and removal of longer hairs.

ENGLISH

5) Cleaning and care

Wet cleaning



The shaving head and cutter blocks can be very conveniently cleaned under lukewarm flowing water. The water temperature must be less than 70° C.

The shaver is not waterproof, however.


Press the two release buttons ⑨ on the sides (Fig. 4).

Now switch your shaver on again and hold the cutter block under warm flowing water (Fig. 4). The swirling movement of the water, combined with the counter-running cutter blocks, results in thorough cleaning.

ATTENTION: Never immerse the entire shaver in water.

To promote the cleaning effect and for pleasant freshness, you can also use commercially available liquid soap. Before switching the device on, place a few drops of liquid soap on the shaving head and cutter block. Rinse thoroughly with warm flowing water, and then switch the shaver off again. Allow the shaver to dry well before you replace the shaving head.


From time to time, spread a few drops of sewing machine oil on the cutter blocks ④ and on the long-hair trimmer ⑤ in order to retain the device's operational performance. Use only a moistened cloth to clean the case.



Cleaning without water

The shaver can also be cleaned without water.

- Press the two shaver head release buttons ⑧ and pull the shaver head ② from the casing (Fig. 5).



- Tap the shaver head on a flat surface or blow the hairs out thoroughly. Never use the brush for cleaning the foil as this may

damage it. Clean the cutter blocks with the enclosed cleaning brush (Fig. 6).



6) Changing foil and cutter blocks


Shaving performance depends on the condition of the foil ③ and the cutter blocks ④. Both wear gradually in use. Therefore we recommend the following changing intervals:

- **Shaving foil:** once a year Type 78, Order No. RPS 7800
- **Cutter block:** every 2 years Type 70, Order No. RPS 7000

Important
Only the changing of both elements guarantees best shaving performance.

Replacing the shaving foil

- Remove the shaver head ② by pressing the two release buttons ⑧ (Fig. 5).
- Pull the shaving foil ③ out of the shaver head by holding it on the attached straps (Fig. 7).




Attention !
Hold the shaving foil only at the straps to prevent damage !

- Place the new shaving foil in the shaver head until it clicks in position.
- Replace the shaver head.

ENGLISH

Replacing the cutter blocks

- Remove the shaver head ②.
- Hold the cutter blocks ④ on both sides and lift them from their supports (Fig. 8).




- Place the new cutter blocks in position
- Replace the shaver head.

7) Replacement parts

When ordering replacement parts (shaving foil and cutter blocks) please indicate the type of shaver according to the rating plate indication on the casing under the shaver head.

XENIC



- **Netz- / Akkugerät**
- **Mains- / Rechargeable**

CE

9191